

January 2024

BAND-IT Plastic Tote Dispenser

BAND-IT have made a decision to align their plastic tote dispensers with the rest of the BAND-IT group, thus resulting in a change to the current product design. This change in design is to ensure continuity of supply and minimise any impact to current finished product lead times. **Existing colour configurations will remain the same and there is no change to the strapping encased in the dispenser. The change is highlighted below.**

Red Dispenser Old configuration (with black centre piece)



Blue dispenser: new design



The key difference is the removal of the black centre piece which helped the strapping come off the roll. The new dispenser can be used in a similar way to the previous dispenser. If the strapping becomes “jammed”, please following the following simple steps:

Step One – Allow the strapping to recoil into the plastic dispenser. If “jammed”, give the dispenser a shake to release the strapping. Then shake the dispenser slightly to allow the band to loosen, which will allow the band to move freely. Please note under no circumstances should you open the dispenser.



Step Two – Once recoiled and loose, feed the end back through the indicated slot below. Again, you may need to shake the case to move the strapping towards the opening.



Step Three – Use the dispenser as normal.



Auckland

RTL Auckland

Wellington

31 Maurice Road, Penrose,

Christchurch

Auckland 1061, New Zealand

P +64 9 259 2600

Invercargill

P O Box 14111, Panmure, Auckland

E sales@rtl.co.nz

0800 785 744

rtl.co.nz