

# TMA MAINTENANCE CHECKLIST

**TMAs require regular maintenance. RTL recommends daily checks, monthly greasing, annual TMA inspections, and pivot pin replacement every two years. For more information, visit [www.rtl.co.nz](http://www rtl co nz)**

TASK	BEFORE USE	WEEKLY	MONTHLY	ANNUALLY	BIENNIALLY
Wash off road salt and grime <b>AFTER</b> each use	●	●	●	●	●
Verify TMA raises and lowers properly	●	●	●	●	●
Verify function of all lighting (Tail Lights, Side Marker Lights, etc.)	●	●	●	●	●
Verify that reflective sheeting is present and in good condition	●	●	●	●	●
Check TMA for hydraulic fluid leaks	●	●	●	●	●
Verify that jack crank handles fold up tightly and do not hang down	●	●	●	●	●
Verify that energy absorbing modules and tubes are secure and in good condition	●	●	●	●	●
<hr/>					
Check ride height, adjust if it does not meet 12" ± 1" specification	●	●	●	●	●
Check for loose or missing fasteners and hardware	●	●	●	●	●
Check energy absorbing tube assemblies for cracks and gouges	●	●	●	●	●
Check energy absorbing tube assemblies for broken welds	●	●	●	●	●
Check energy absorbing modules for large dents, punctures, or missing rivets	●	●	●	●	●
Verify TMA Strut tensioning straps are intact	●	●	●	●	●
<hr/>					
Grease pivot points and lockout arm	●	●	●	●	●
Grease jack casters	●	●	●	●	●
Check TMA hydraulic components, valves, and pivot pins of dirt and debris	●	●	●	●	●
<hr/>					
Verify overall dimensions are still within specification	●				
Clean all electrical connections on pump power and controller circuits	●				
Verify structural integrity of all steel attenuator components	●				
Verify structure integrity of truck side mounting components	●				
Verify integrity of all welds	●				
Clean/remove rust and repaint as needed	●				
Drain TMA hydraulic system and replace fluid	●				
Annual TMA Inspection to be completed with RTL				●	
<hr/>					
Replace Pivot Pins with RTL					●

Name: \_\_\_\_\_  
Date: \_\_\_\_\_

Truck Rego:  
TMA Serial Number: \_\_\_\_\_

## TMA Checks, Servicing & Maintenance

**NOTE:** TMAs require regular maintenance. RTL recommends daily checks, monthly greasing, annual TMA inspections, and pivot pin replacement every two years. For more information, visit [www.rtl.co.nz](http://www rtl co nz) or contact our Service Team. Please call us today on 0800 785 744.

## TMA Intended Use - MUST READ

**NOTE:** Truck Mounted Attenuators (TMAs) are designed solely as crash attenuators. They must not be used as a mobile barrier or for any purpose other than crash attenuation and should only be deployed at speeds up to 50 km/h. Use outside these conditions will void the warranty.

**Contact: [services@rtl.co.nz](mailto:services@rtl.co.nz) or 0800 785 744**