


Static IP Change Over Stage 1: Embedded Modems - User Guide (Oct 2025)

Ver-Mac VMS Trailer Communication Update: VPN to Static IP changeover.

VERMAC in Canada is transitioning away from the Virtual Private Network (VPN) setup currently used for Ver-Mac VMS trailers in New Zealand. The following Work Instruction outlines both types of embedded modems (V1 and V2) and the steps required to re-configure them for a static IP data sim.

The image below indicates a trailer with an embedded modem (situated on the back of the touch screen):



Upgrade Process:

- Purchase a public static IP data SIM card (we recommend 2Degrees based on our testing). Ensure you select a minimum 50MB monthly data plan per trailer
- Insert the new sim into the sim slot of the embedded modem (see next page).
- Follow steps to change settings using the touch screen controller (see process)
- Contact our support team services@rtl.co.nz to verify connectivity

Notes: This work instruction is only for Ver-mac Trailers that have a Touchscreen with Embedded Modem.

User Guide V1.1

Auckland

RTL Auckland

Wellington

31 Maurice Road, Penrose,

Christchurch Invercargill

Auckland 1061, New Zealand
P O Box 1411, Panmure, Auckland

P +64 9 259 2600 **E** sales@rtl.co.nz

0800 785 744

rtl.co.nz



Insert New Static IP Data SIM Card into Modem:

- 1. Unlock the trailer control cabinet (keys required)
- 2. Turn black knob & open front cover
- 3. Insert the sim into modem (see below)
- 4. Close black cover & power on trailer
- 5. Log in using your password



Fig.1&2




Fig.1 - Version 1




Fig.2 - Version 2

Do you have an external Modem (WR21 or WR32)?

Please note, the update for VMS with external modems will be released in stage two of the roll out. If you have a trailer with an external modem, please reach out to our team – services@rtl.co.nz



Auckland RTL Auckland

Wellington Christchurch

31 Maurice Road, Penrose,
Auckland 1061, New Zealand

Invercargill P O Box 1411, Panmure, Auckland

P +64 9 259 2600 **E** sales@rtl.co.nz

0800 785 744

rtl.co.nz



Instructions to Change Embedded Modem Configuration

Introduction:

These are the steps for migrating dynamic to static IP data sims. Once you have inserted the new sim card, follow the steps below. Settings are done on the touch controller.

• Fig.3 - On the Home Screen Select Toggle (1) > Options (2) Click Page > Modem (3)




Fig.3

• Fig.4 - In the modem settings select Configuration



Fig.4



 Fig.5 - In Configuration select Modem Config. > select CUTSOM (First selection on the top of the Menu)





Fig.5

• **Fig.6** - Uncheck the Use VPN check box > Manually insert the APN (This is provided by the Public Static SIM provider)



P +64 9 259 2600

E sales@rtl.co.nz

Fig.6



• Fig.7 - Select APN, 2DCORPORATE, for 2Degrees public static data SIM > Save

VMModem Firmware:	V0000.004	
Modem Model:	QuectelEC21	
Modem Config:	Custom	
APN:	2DCORPORATE	
User:		
Password:		
Back	Use VPN:	Save

Fig.7

• Fig.8 - Click Parameters (1) > Click Comm Parameters (2)




Fig. 8



• Fig.9 – Note down the IP Address number (1). Click Home for main screen (2)



Fig. 9

Update Trailer IP Address in JAMLOGIC



• Fig.10 – Login into JAMLOGIC on your Computer (1)
Right click on the Trailer (2) > Click Communication Settings (3)




Fig. 10



• **Fig.11** – Under Network Settings Type in new IP address (1) into Address Field. Click Save (2)




Fig. 11

• Fig.12 - To test connection Right Click on Trailer (1) and Get Status (2).




Fig. 12



Verifying Connection / Additional Support:

If you need assistance to verify connectivity, please don't hesitate to contact our support team services@rtl.co.nz. Please have trailer rego and the new IP address from the trailer on hand.

Additional Support:

We understand that changes to your equipment require coordination and planning. RTL is committed to making this transition as smooth as possible:

- 1. Technical support available on **Book a Service** or services@rtl.co.nz
- 2. Step-by-step guidance for SIM setup and configuration
- 3. Verification assistance to ensure your trailer is properly connected

We look forward to partnering with you on this update.

Safety and service remain our foundational commitments, and this update supports both by ensuring the continued reliability of your traffic management equipment.